

27-40MHz Multi Frequency Instruction

Step- 1

Factory testing code deleting. Simultaneously press and hold button A and button B until LED flashes 3 times. Keep pressing button A.

Release button Disarm then press button B slowly 3 times, LED flashing.

Release button A. Factory code is now deleted. If all has been done correctly then after short pressing of any button LED light will not flash.

Step- 2

Place the original remote control and copy remote control as close as possible together (back to back). Press and hold one button on your original remote and the button on copy remote control, which you wish.

To be programmed on at the same time for approximately 3 seconds. LED indicator then flashes three times, followed by a continuous fast blinks, indicating that the button is successfully copied. Repeat the above clone step for other buttons you wish to copy.



26-41MHz Fixed Code

26.720MHz, 26.975MHz
27.015MHz, 27.195MHz
27.575MHz, 27.745MHz
29.800MHz, 29.820MHz
30.035MHz, 30.075MHz
30.545MHz, 30.875MHz
30.925MHz, 33.155MHz
40.685MHz. etc.